



WIFLY GSX

RN-131G & RN-134

802.11 b/g wireless LAN Module

User Manual and Command Reference

Version 2.12
September 17, 2009

Copyright © 2009 Roving Networks, Inc. All Rights Reserved.

The contents of this document can be changed by Roving networks without prior notice and do not constitute any binding undertakings from Roving networks. Roving Networks is not responsible under any circumstances for direct, indirect, unexpected or consequent damage that is caused by this document.

1	Overview.....	3
2	Hardware Interface	4
2.1	Power.....	4
2.2	Reset.....	4
2.3	UART.....	4
2.4	Status Indictors	5
3	Configuration.....	5
3.1	Entering Command Mode	5
4	WiFly Command Reference	7
4.1	Command Syntax	7
4.2	Command Organization	7
5	SET Commands.....	8
5.1	ADHOC Parameters	8
5.2	BROADCAST Parameters.....	8
5.3	COMM Parameters.....	8
5.4	DNS Parameters	9
5.5	FTP Parameters	9
5.6	IP Parameters.....	9
5.7	OPTIONAL Parameters	10
5.8	SYSTEM Parameters	11
5.9	TIME Server Parameters	12
5.10	UART Parameters.....	12
5.11	WLAN Parameters	12
6	GET Commands	15
7	STATUS Commands.....	16
8	ACTION Commands.....	18
9	FILE IO Commands.....	19
10	Advanced Features and Settings	20
10.1	System Timers and Auto Connect Timers	20
10.2	Wake on Sensor Input	20
10.3	Wake on UART.....	21
10.4	UART Receiver, RTS/CTS Hardware Flow Control.....	21
10.5	Setting GPIO direction, Alternate Functions and Disabling LEDs	22
10.6	Setting Debug Print levels.....	24
10.7	Using the Real Time Clock Function	24
10.8	Using the UDP Broadcast function	25
11	Joining Networks and Making Connections.....	27
11.1	Associate with a network access point	27
11.2	Making Connections	28
11.3	Setting up Automatic Connections.....	28
11.4	Controlling Connections using PIO5 and PIO6	29
11.5	Using DNS settings	29
11.6	Utilizing the Backup IP address/connect function.....	29
12	Firmware Upgrade over FTP.....	29
13	Adhoc Networking Mode.....	31
13.1	Infrastructure and adhoc comparison	31
13.2	Configuring adhoc mode	31
14	Analog Sensor Capability.....	33
15	Default Configuration Settings	34
15.1	Restoring Default configuration settings:	35
16	Boot-up Timing Values.....	36
17	Supported Access Points	36
18	Release Notes.....	37
18.1	Known problems	37
18.2	Current Firmware features and fixes.....	37

1 Overview

The “WiFly” radio module is a complete stand alone embedded wireless LAN access device. The device has on board TCP/IP stack and applications. Requiring only 4 pins (POWER, TX, RX, GND) to design in. Once initial configuration is set, the radio can automatically access the WiFi network and send/receive serial data over UART.

- Fully Qualified and Wifi Certified 2.4GHz IEEE 802.11b/g transceiver
- High throughput, up to 4Mbps sustained data rate with TCP/IP and WPA2
- Ultra-low power (4uA sleep, 40mA Rx, 210mA max Tx)
- Small, compact surface mount module
- On board ceramic chip antenna and U.FL connector for external antenna
- 8 Mbit flash memory and 128 KB RAM
- UART and SPI (future) data/control interfaces
- 10 general purpose digital I/O
- 8 analog inputs
- Real-time clock for wakeup and time stamping/data logging
- Accepts 3.3V regulated or 2-3V battery with on board boost regulators
- Supports Adhoc and Infrastructure mode connections
- On board ECOS-OS, TCP/IP stacks
- Wi-Fi Alliance certified for WPA2-PSK
- FCC / CE/ ICS certified and RoHS compliant

Features

- Host Data Rate Up to 2.7 Mbps for UART
- Memory 128 KB RAM, 2MB ROM, 2 KB battery-backed memory, 8 Mbit Flash.
- Intelligent, built-in power management with programmable wakeup
- Can be powered from regulated 3.3-3.7V source or 2.0-3.0V batteries
- Real time clock for time stamping, auto-sleep and auto-wakeup modes
- Configuration over UART or wireless interfaces using simple ASCII commands
- Over the air firmware upgrade (FTP), and data file upload.
- Secure WiFi authentication WEP-128, WPA-PSK (TKIP), WPA2-PSK (AES).
- Built in networking applications DHCP client, UDP, DNS client , ARP, ICMP ping, FTP, HTTP
- 802.11 power save and roaming functions

2 Hardware Interface

See the RN-131 or RN-134 data sheets on the Roving Networks website for technical specifications and layout information of these modules.

2.1 Power

There are two options for powering the RN-131G module directly.

DC SUPPLY: Apply 3.3 VDC power to VBATT (pin 20), and V3.3IN (pin 21)
Tie 3.3VREG-IN (pin 18) to GROUND. 3.3V-REG-OUT (Pin 17) leave floating.

BATTERY: Apply battery = 2.0 to 3.3VDC to VBATT (pin 20). V3.3IN pin 21 = floating.
Tie pin 17 to pin 18. (this enables the on board battery boost 3.3V switcher).

There is a built in voltage brownout monitor which will shut down the chip when the voltage drops below 2.0 VDC.

Warning: Do NOT exceed the voltage ratings on the 3.3V pins, damage to the module will result.

Notes:

#1: The Sensor inputs SENS0-7 are extremely sensitive to over voltage. Under no conditions should these pins be driven above 1.2VDC. Placing any voltage above this will permanently damage the radio module and render it useless.

#2: Placing 5VDC or any voltage above 3.3Vdc into the VDD pins of the module will permanently damage the radio module.

#3: Placing 3.3Vdc into the PIO's while they are set as outputs will permanently damage the module. The failure mode is a short across GND and VCC.

2.2 Reset

Reset is active LOW and is optional/does not need to be connected. The reset pin is 3.3V tolerant and has an internal pull up of 100K to the VBATT.

2.3 UART

Connect a common ground when using the external TX, RX inputs.

For a 3 wire DB-9 interface (connect tx, rx, gnd only)

Factory default is hardware flow control disabled, CTS and RTS are not required.

When using a 5.0 VDC Input, PIO's and UART input pins require a resistor divider. A suggestion is 10K in series with 20k to ground. PIO's are 0-3.3 VDC not 5.0 VDC tolerant.

2.4 Status Indicators

PIO 4, 5 and 6 are active high and can be connected to external LEDs to provide network, connection and data status.

Condition	PIO6=Red LED	PIO5=Yellow LED	PIO4=Green LED
ON solid	Not Associated		Connected over TCP
Fast blink		Rx/Tx data transfer	No IP address
Slow blink	Associated, No Internet		IP address OK
OFF	Associated, Internet OK		

3 Configuration

3.1 Entering Command Mode

Upon power up, the device will be in data mode. To enter command mode, exactly the three characters **\$\$\$** must be sent. The device will respond with **CMD**.

While in command mode, the device will accept ASCII bytes as commands. To exit command mode, send **exit<cr>**. The device will respond with "EXIT".

Parameters, such as the SSID, channel, IP address, Serial Port settings, and all other settings can be viewed and configured in command mode.

ASCII characters can be sent through a terminal emulator connected to the UART or via Telnet. When using the UART communications settings should match the settings used when RN-131g connects, for example: the default is 9600 baudrate, 8 bits, No Parity, 1 stop bit, and hardware flow control disabled.

Run your favorite terminal emulator, Roving Networks provides a free one, Teraterm, at <http://www.rovingnetworks.com/support/teraterm.zip>.

Type **\$\$\$** on in the terminal emulator. You should see "**CMD**" returned to you. This will verify that your cable and comm. settings are correct. Most valid commands will return an "**AOK**", response, and invalid ones will return an "**ERR**" description.

To exit command mode, type **"exit"<cr>**.

NOTE: You can enter command mode locally over the UART interface at any time when not connected, and also when connected if the appropriate settings are enabled.

Remote configuration using ADHOC mode

Using adhoc mode to configure the device eliminates the need for the module to be associated with a network access point. In adhoc mode the module creates it own "on demand" network that you can connect to via your computer like you would to any other network.

To enable adhoc mode via hardware set *PIO9* high (3.3V) at power up. On the RN-134 *PIO9* is on the J1 jumper block. When the module powers up with *PIO9* set high, the WiFly module creates an adhoc network with the following

SSID: WiFly-GSX-XX where XX is the final two bytes of the devices MAC address

Channel: 1
DHCP: OFF
IP address: 169.254.1.1
Netmask: 255.255.0.0

With the adhoc jumper in place the above settings override the current saved configuration settings.

From your computer, connect to the WiFly-GSX-XX network. This is an open network which does not require a pass phrase or pass key. Note: currently the WiFly only supports OPEN mode for creating adhoc networks.

NOTE: It may take a couple of minutes for Auto IP in Windows to assign an IP address and connect to the network. You can check IP address of your Windows computer by running the **ipconfig** command in the command window. If connected, this command will show you the IP address and net mask for your computer.

The IP address assigned by Auto IP must be on the subnet 169.254.1.X otherwise the WiFly GSX module will not be accessible.

NOTE: If your machine has both a wireless and wired interface hardware you will need to disable the wired LAN interface hardware before connecting to the adhoc network. If the wired LAN is enabled the computer will assign an IP address that is not on the same subnet as the WiFly module.

Once connected and you have a good IP address, telnet into the WiFly module on port 2000

telnet 169.254.1.1 2000

You should see the response **"*HELLO*"**

You can now enter command mode and configure the module.

4 WiFly Command Reference

4.1 Command Syntax

Commands begin with a keyword, and have optional additional parameters, generally space delimited. Commands and options **are** case sensitive. Hex input data can be upper or lower case. String text data, such as SSID is also case sensitive.

The first command is fully decoded and must be complete. Other command parameters can be shorted by using only the first character.

For example,

set uart baudrate 115200 is valid,
set uart b 115200 is also valid,
set u b 115200 is also valid, however,
s uart baudrate 115200 is NOT valid.

Numbers can be entered as either decimal, (like 115200 above) or HEX. To enter HEX, use **0x<value>**. For example, the HEX value FF would be entered as 0xFF.

4.2 Command Organization

Commands fall into 5 general categories:

- SET COMMANDS** -Take effect immediately, permanently (save command issued).
- GET COMMANDS** -Retrieve the permanently stored information for display to user.
- STATUS COMMANDS** -See what is going on with the interface, IP status, etc.
- ACTION COMMANDS**- Perform action such as scan, connect, disconnect, etc.
- FILE IO COMMANDS** - Upgrade, load and save configuration, delete files, etc.

NOTE: You must save any changes made or the module will load the previous settings upon reboot or power up.

When the system boots, all configuration data is loaded into RAM variables from the file called "config". The set commands actually only modify the RAM copy of variables in the system. In general, the IP, WLAN and UART settings need a save and reboot to take effect, since they operate at boot up time. For example you only associate, set the channel and get your ip address once at power up.

Most of the other commands take effect immediately like the COMM settings and timers. This allows temporary change of parameters "on the fly" to test features, minimizes power usage and saves on flash re-write cycles.

Once all configuration is complete, the user must save the settings using the **save** command to store the configuration data, otherwise it will not take effect upon reboot or reset. Multiple configurations can be stored by using the **save <filename>** command, and these configurations can be loaded using the **load <filename>** command.

5 SET Commands

These commands begin with "set". There are 6 major categories.

ADHOC	- controls the adhoc parameters
BROADCAST	- controls the broadcast hello/heartbeat UDP message
COMM	- communication and data transfer, timers, matching characters
DNS	- DNS host and domain
FTP	- FTP host address and login information
IP	- IP settings
OPTION	- optional and not frequently used parameters
SYS	- system settings such as sleep and wake timers
TIME	- timer server settings
UART	- serial port settings such as baudrate and parity
WLAN	- wireless interface settings, such as ssid, chan, and security options

5.1 ADHOC Parameters

set adhoc beacon <ms> sets the adhoc beacon interval in miliseconds. Default is 100.

set adhoc probe <num> sets the adhoc probe retry count. Default is 9.

5.2 BROADCAST Parameters

set broadcast address <addr> sets the address to which the UDP hello/heartbeat message is sent. The default address is 255.255.255.255

set broadcast interval <value> sets the interval at which the hello/heartbeat UDP message is sent. Interval is specified in seconds. The value is a mask that is compared to a free running seconds counter. For example if interval = 0x7, a packet will be sent every 8 seconds. If minimum interval value is 0x01 = every 2 seconds and max value is 0xff = every 256 seconds. Setting the value to zero turns off the UDP broadcast. The default interval is 7.

set broadcast port <port> sets the port number to which the UDP hello/heartbeat message is sent. The default port is 55555.

5.3 COMM Parameters

set comm close <string> sets the ASCII string that is sent to the local UART when the TCP port is closed. If no string is desired, use 0 as the <string> parameter. Max string length is 32 characters. Default is *CLOS*

set comm open <string> sets the string that is sent to the local UART when the TCP port is opened. If no string is desired, use 0 as the <string> parameter. Max string length is 32 characters. Default is *OPEN*

set comm remote <string> sets the string that is sent to the remote TCP client when the TCP port is opened. If no string is desired, use 0 as the <string> parameter. Max string length is 32 characters. Default is *HELLO*

- set comm idle <secs>** sets the Idle Timer Value. This is the number of seconds with no transmit or receive data before the connection is closed automatically. Default is 0, never disconnect on idle.
- set comm match <value>** sets matching character initiate forwarding data across the TCP/IP connection. The value is entered as the decimal value of the of the ASCII character. Default is 0, disabled. For more information see section 10.4.
- set comm size <value>** sets the Flush Size value. This is the number of bytes to receive on the UART before forwarding. 0 disables forwarding based on byte count. Default is 64 bytes (at 9600). Maximum value = 1420 bytes.
- NOTE: This value is set automatically when the baudrate is set, in an attempt to optimize the link. It is assumed that higher baudrates suggest larger buffer sizes and hence the size will increase at higher baudrate settings.*
- set comm time <num>** sets the Flush Timer. This is the number of 1 millisecond intervals after the last UART byte is received before the data is sent over Wifi. 1 is the minimum value. Default is 10 (10 milliseconds). Setting this value to 0 will disable forwarding based on time delay.

5.4 DNS Parameters

- set dns address <addr>** sets the IP address of the DNS sever. This is auto-set when using DHCP, and needs to be set in STATIC IP or Auto-IP modes.
- set dns name <string>** sets the name of the host for TCP/IP connections.
- set dns backup <string>** sets the name of the backup host for TCP/IP connections.

5.5 FTP Parameters

- set ftp filename <file>** sets the name of the file transferred when issuing the "ftp u" or "ftp g" commands.
- set ftp addr <addr>** sets the ftp server IP address.
- set ftp remote <port>** sets the ftp server remote port number (default is 21).
- set ftp user <name>** sets the ftp user name for accessing the FTP server.
- set ftp pass <pass>** sets the ftp password for accessing the FTP server.

5.6 IP Parameters

- set ip address <addr>** sets the IP address of the WiFly GSX module. If DHCP is turned on, the IP address is assigned and overwritten during association with the access point. IP addresses are "." delimited. Note this is different from the RN-111b module which is space delimited!

Example: "set ip a 10.20.20.1"

set ip dhcp <value>

enable/disable DHCP mode. If enabled, the IP address, gateway, netmask, and DNS server are requested and set upon association with access point. Any current IP values are overwritten.

DHCP Cache mode can reduce the time it takes the module to wake from deep sleep thus saving power. In cache mode, the lease time is checked and if not expired the module uses the previous IP settings. If the lease has expired the module will attempt to associated and use DHCP to get the IP settings.

Mode	Protocol
0	DHCP OFF, use stored static IP address
1	DHCP ON, get IP address and gateway from AP
2	Auto-IP, generally used with Adhoc networks
3	DHCP Cache mode, Uses previous IP address if lease is not expired (lease survives reboot)
4	Reserved for future use

set ip gateway <addr>

sets the gateway IP address, If DHCP is turned on, the gateway IP address is assign and overwritten during association with the access point.

set ip host <addr>

sets the remote host IP address. This command is used for making connections from the WiFly module to a TCP/IP server at the IP address <addr>.

set ip backup <addr>

sets a secondary host IP address.

set ip localport <num>

sets the local port number.

set ip netmask <value>

sets the network mask. If DHCP is turned on, the net mask is assign and overwritten during association with the access point.

set ip protocol <value>

sets the IP protocol. Value is a bit mapped setting. To connect to the WiFly GSX module over TCP/IP such as Telnet the device must have the use the TCP Server protocol / bit 2 set. To accept both TCP and UDP use value = 3 (bit 1 and bit 2 set)

Bit Position	Protocol
1	UDP
2	TCP Server & Client (Default)
3	Secure (only receive packets with IP address matches the store host IP)
4	TCP Client only
5	HTTP (future use)

set ip remote <value>

sets the remote host port number.

5.7 OPTIONAL Parameters

- set opt jointmr <secs>** Join timer is the time in seconds the join function will wait for the an access point to complete the association process.
- set opt replace <char>** replacement character for spaces. The replacement character is used when entering SSID and pass phrases that include space. This is used by the WiFly GSX command parser only. Each occurrence of the replacement character is changed into a space. The default is "\$" (0x24)
- set opt deviceid <string>** Configurable Device ID - can be used for storing serial numbers, product name or other device information. This information is sent as part of the broadcast hello packet that is sent as a UDP. The current value can be shown with the "get option" or "show deviceid" commands. Max string size is 32 bytes. The default is "WiFly-GSX".
- set opt password <string>** TCP connection password. Used to challenge the remote device to authenticate the connection. When set all incoming connections will be challenged and the first characters sent must match the stored password or the connection will be closed. When the password is set the WiFly module will send the string "PASS?" to the remote connection. All characters in the string must be sent in one TCP packet. Max string size is 32 bytes. To disable the password feature use string=0 which is the default.

5.8 SYSTEM Parameters

- set sys autoconn <secs>** TCP mode: sets the auto connect timer. This command causes the module periodically connect to the host. The timer <secs> determines how often to connect to the stored remote host. If set to 1, the module will only make one attempt to auto connect upon power up. If set to 2 or greater auto connect will re-open the connection after the connection is closed. Default=0 disables.
- set sys autosleep <num>** Sets the auto-sleep timer. 0 disables. If the protocol is set to UDP ONLY, this timer is used as a quick sleep function. Device will sleep <num> ms after transmission of the first UDP packet.
- set sys iofunc <value>** sets the IO port alternate functions. Bit-mapped value. For more details see section 10.5
- set sys mask <mask>** sets the IO port direction mask. Bit-mapped value. For more information see section 10.5
- set sys printlvl <value>** sets numerous print functions. 0 = quiet 1 = connect information Default is 1.
- set sys output <value> <mask>** sets output PIO pins to HIGH or LOW. Bit-mapped value. Optional mask only sets a subset of pins.
- set sys sleep <secs>** sets the sleep timer. 0 disables.

NOTE: If not using Sensor pins to wake the module, be sure to set the wake timer before issuing the sleep timer or the module will not wake up.

See section 10.1 for more details on using system timers

set sys trigger <value> sets the sensor input(s) to wake on (1-4). Bit-mapped value. 0 disables.

set sys wake <secs> sets the auto wake timer. 0 disables. See section 10.1 for more details on using system timers

5.9 TIME Server Parameters

set time address <addr> sets the time server address. (sNTP servers)

set time port <num> sets the time server port number. Defaults to 123 which is almost always the sNTP server port.

set time enable <value> Enable or disable fetching time from the specified sNTP time server. Default=0= disabled. A value of 1 gets time only once on power up. Any value > 1 gets time continuously every <value> minutes.

5.10 UART Parameters

set uart baud <rate> set the UART baud rate. Valid settings are {1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, 921600}.

Example : "set u b 9600" sets the baud rate to 9600 baud.

set uart instant <rate> This immediately changes the baudrate. This is useful when testing baudrate settings, or switching baudrate "on the fly" remotely while connected over TCP. This setting does not affect configuration. Returns the AOK response, and then this command will exit command mode.

set uart raw <rate> sets a RAW UART value. Used to set non-standard rates.

Example : "set u r 7200" sets the baud rate to 7200 baud.

set uart flow <0,1> sets the flow control mode. Default=0=off, 1= hardware RTS/CTS.

set uart tx <0, 1> Disables or enables the TX pin= PIO10 of the UART. Disable will set PIO10 to an INPUT with weak pulldown.

NOTE: Due to an issue in the UART hardware, the UART does not support even or odd parity.

5.11 WLAN Parameters

set wlan auth <value> Sets the authentication mode. Not needed unless using auto join mode 2. i.e. **set wlan join 2**

Note: During association the WiFly module interrogates the Access Point and automatically selects the authentication mode.

The current release of Wifly firmware supports these security modes:

- WEP-128 (open mode only, NOT shared mode)
- WPA2-PSK (AES only)
- WPA1-PSK (TKIP only)
- WPA-PSK mixed mode (some APs, not all are supported)

Value	Authentication Mode
0	Open (Default)
1	WEP-128
2	WPA1
3	Mixed WPA1 & WPA2-PSK
4	WPA2-PSK
5	Not Used
6	Adhoc, Join any Adhoc network

set wlan channel <value> sets the wlan channel, 1-13 is the valid range for a fixed channel. If 0 is set, then scan is performed, using the ssid, for all the channels set in the channel mask.

set wlan ext_antenna <0, 1> determines which antenna is active, use 0 for chip antenna, 1 for U.F.L connector. Default = 0. Only one antenna is active at a time and the module must be power cycled after switching the antenna.

set wlan join <value> sets the policy for automatically joining/associating with network access points. This policy is used when the module powers up, including wake up from the sleep timer.

Value	Policy
0	Manual, do not try to join automatically
1	Try to join the access point that matches the stored SSID, passkey and channel. Channel can be set to 0 for scanning. (Default)
2	Join ANY access point with security matching the stored authentication mode. This ignores the stored SSID and searches for the access point with the strongest signal. The channels searched can be limited by setting the channel mask.
3	Reserved – Not used
4	Create an Adhoc network, using stored SSID, IP address and netmask. Channel MUST be set. DHCP should be 0 (static IP) or set to Auto-IP with this policy. (unless another Adhoc device can act as DHCP server) This policy is often used instead of the hardware jumper to create a custom Adhoc network

set wlan hide <0, 1> Hides the WEP key and WPA passphrase. When set, displaying the wlan settings shows ***** for these fields. To unhide the

passphrase or passkey, re-enter the key or passphrase using the set wlan key or set wlan passphrase command. Default = 0, don't hide.

wlan key <value>

sets the 128 bit WEP key. If you are using WPA or WPA2 you should enter a pass phrase with the set wlan passphrase command. Key must be EXACTLY 13 bytes (26 ASCII chars). Data is expected in HEX format, "0x" should NOT be used here.

Example : "set w k 112233445566778899AABBCCDD"

Hex digits > 9 can be either upper or lower case.

The Wifly GSX only supports "open" key mode, 128 bit keys for WEP. WEP-128, shared mode is not supported as it is known to be easily compromised and has been deprecated from the WiFi standards.

set wlan mask <value>

sets the wlan channel mask used for scanning channels with the auto-join policy 1 or 2, used when the channel is set to 0. Value is a bit-map where bit 0 = channel 1. Input for this command can be entered in decimal or hex if prefixed with 0x. Default value is 0x1FFF (all channels)

set wlan num <value>

sets the default WEP key to use. 1-4 is the valid range.

Example : "set w n 2" sets the default key to 2.

set wlan phrase <string>

sets the passphrase for WPA and WPA2 security modes. 1-64 chars. The passphrase can be alpha and numeric, and is used along with the SSID to generate a unique 32 byte Pre-shared key (PSK), which is then hashed into a 256 bit number. Changing either the SSID or this value re-calculates and stores the PSK.

If exactly 64 chars are entered, it is assumed that this entry is already an ASCII HEX representation of the 32 byte PSK and the value is simply stored.

Example : "set w p password" sets the phrase.

set wlan ssid <string>

sets the wlan ssid to associate with. 1-32 chars.

NOTE: If the passphrase or ssid contain the SPACE (` `) characters, these can be entered using substitution via the "\$" character.

For example, if the ssid of the AP is "yellow brick road"
You would enter "yellow\$brick\$road"

Using the `get w` command will properly display the value:
SSID=yellow brick road.

set wlan rate <value>

sets the wireless data rate. Lowering the rate increases the effective range of the WiFly-GSX module. The value entered is mapped according to the following table

Value	Wireless Data Rate
0	1 Mbit/sec
1	2 Mbit/sec
2	5.5 Mbit/sec
3	11 Mbit/sec
4 - 7	Invalid
8	6 Mbit/sec
9	9 Mbit/sec
10	12 Mbit/sec
11	18 Mbit/sec
12	24 Mbit/sec (default)
13	36 Mbit/sec
14	48 Mbit/sec
15	54 Mbit/sec

set wlan window <value> sets the IP maximum buffer window size. Default is 1460 bytes.

6 GET Commands

These commands begin with "get". They display the current values.

- get adhoc** display all adhoc settings.
- get broadcast** will display the broadcast UDP address, port and interval
- get everything** displays all configuration settings, useful for debug.
- get com** display comm. settings.
- get dns** display DNS settings.
- get ftp** display FTP settings.
- get ip** display IP address and port number settings.
- get mac** display the device MAC address.
- get optional** display the optional settings like device ID
- get port** return current value of the PIO pins in hex format.
- get sys** display system settings, sleep, wake timers, etc.
- get time** display the time server UDP address and port number.
- get wlan** display the ssid, chan, and other wlan settings.

- get uart** display the UART settings.
- ver** return the software release version

7 STATUS Commands

These commands begin with "show", and they return the current values of variables in the system. In some cases, for example IP addresses, the current values are received from the network, and may not match the stored values.

show battery Displays current battery voltage, (only valid for Roving battery powered product like the RN-370 and temperature sensors)

show connection Displays connection status in this HEX format: 8XYZ

Bit location	13-16	9-12	7	6	5	4	0-3
Function	fixed	channel	DNS found	DNS server	Authen	Assoc	TCP status
Value	8	1-13	1=resolved	1= contacted	1= OK	1=OK	0= Idle, 1=Connected 3= NOIP 4= Connecting

show io Displays IO pin levels status in this HEX format: 8ABC
 Example: show I returns 8103 indicates pins 0, 1 and 9 high level.

show net Displays current network status, association, authentication, etc.

show rssi Displays current last received signal strength.

show stats Displays current statistics, packet rx/tx counters, etc.

show time Displays number of seconds since last powerup or reboot

show q <0-7> Display the value of the an analog interface pin from 0 to 7. The value returned will be in the format 8xxxxx where xxxxx is voltage in microvolts sampled on the channel you request with the 8 in front as a start marker.

show q 0x1<mask> Displays multiple analog interface values at once. The channels displayed is controlled by a bit mask which is preceded by a 0x1xx where xx mask is the bit mask of the channels. For example, to read channels 0,1, and 7, send:

show q 0x183

Which returns 8<chan0>, 8<chan1>, 8<chan7>, \r\n

8 ACTION Commands

\$\$\$	enter command mode Characters are PASSED until this exact sequence is seen. If any bytes are seen before these chars, or after these chars, in a 250ms window, command mode will not be entered and these bytes will be passed on to other side.
close	disconnect a TCP connection.
exit	exit command mode. Exit command mode. "EXIT" will be displayed.
factory RESET	Loads factory defaults into the RAM configuration. Note that the RESET must be capitalized. After this command the new settings must be save to the config file using the save command and the module rebooted for them to take effect.
join <ssid>	joins the network <ssid>. If network is security enabled you must set the pass phrase with the set wlan phrase command prior to issuing the join command
join # <num>	join a network from the scan list. <num> is the entry number in the scan list that is returned from the scan command. If network is security enabled you must set the pass phrase with the set wlan phrase command prior to issuing the join command
leave	disconnects from currently associated Access Point.
open <addr> <port>	opens a TCP connection to the given IP port and address. If no arguments are provided, the device will attempt to connect to the stored remote host IP address and remote port number. <addr> can also be a DNS hostname and will be resolved if entered.
Ping <g h i addr> <num>	ping remote host. Default sends 1 packet. Optional <num> sends <num> pings at 10 per second. Ping 10.20.20.12 10 – pings IP address 10 times
ping g	pings the gateway, the gateway IP address is loaded if DHCP is turned on, otherwise it should be set with the set ip gateway <addr> command
ping h	pings the stored host IP address, the host IP address can be set with the set ip host <addr> command
ping i	pings a known Internet server at www.neelum.com by first resolving the URL (proves that DNS is working and proves the device has internet connectivity).
ping 0	terminates a ping command
reboot	forces a reboot of the device (similar to power cycle)

- scan <time>** Performs an active probe scan of access points on all 13 channels. Returns MAC address, signal strength, SSID name, security mode. Default scan time is 200ms / channel = about 3 seconds. **time** is an optional parameter, this is the time in ms per channel. For example, "scan 30" reduces the total scan time down to about 1 second. This command also works in Adhoc mode (version 2.11).
- time** Sets the Real time clock by synchronizing with the time server specified with the time server parameters (see section 5.9) This command sends a UDP time server request packet.

9 FILE IO Commands

- del <name> <num>** Deletes a file. Optional <num> will override the name and use the sector number shown in the "ls" command.
- load <name>** Reads in a new config file.
- ls** Displays the files in the system
- save** Saves the configuration to "config" (the default file).
- save <name>** Saves the configuration data to a new file name
- boot image <num>** Makes file <num> the new boot image.
- ftp get <name>** Retrieves a file from the remote FTP server. If <name> not specified, the stored ftp filename is used.
- ftp update <name>** Deletes the backup image, retrieves new image and updates the boot image.

10 Advanced Features and Settings

10.1 System Timers and Auto Connect Timers

There are 2 timers that can be used to put the module to sleep, and perform a wake up. If the sleep timer is enabled, the module will automatically go into deep sleep, low power mode once the timer counts down to 0. The sleep timer is disabled if the module has an IP connection, or the module is in COMMAND mode. The timer is reset when characters are received on the UART.

The sleep timer is set with : **set sys sleep <time>** time=decimal in seconds.

The wake timer will bring the module out of deep sleep.

The wake timer is set with: **set sys wake <time>** time=decimal in seconds.

For example, if you wanted the module to wake up, join a network and be available to accept TCP connections for 30 seconds every 2 minutes you would set the timers as such

```
set wlan ssid my_net  
set wlan passphrase my_pass  
set sys sleep 30  
set sys wake 90  
save  
reboot
```

UDP sleep, and Connection timers

There is another timer than can be used to put the device to sleep.

In UDP protocol mode, the autoconn timer is used as an auto-sleep timer.

Upon the start of transmission of the first UDP data packet this timer will count down.

set sys autosleep <value> UDP mode: sets the auto-sleep timer. 0 disables

the timer is decremented every xx milliseconds, based on the value of the comm flushtimer. Using a minimum value of 2 (when the default flushtime=10 ms) is recommended to ensure that the UDP packet gets transmitted. For larger packets the value should be increased.

In TCP-Client mode, the auto-conn timer is used as a connect out timer. If set, the device will automatically attempt a connection when the timer expires.

```
set sys autoconn <secs>
```

In TCP-Client AND TCP-Server mode, there is also a disconnect timer.

set comm idle <secs> sets the idle disconnect timer. This causes a disconnect if no transmit or receive data is seen.

10.2 Wake on Sensor Input

There are 4 inputs available to wake the module from sleep, SENS0-3..

To enable 1 of these inputs, use: **set sys trigger <value>**. 0 disables. This is a bit-mapped setting. To wake on sensor pin 2, you would use **set sys trig 4**, for example.

The **SENSE** inputs do NOT have a resistor divider to allow pins to tolerate 3V logic. So a minimum of 24K in series with 10K to ground as a divider network from the UART RX or CTS pin should be used.

WARNING: Under no conditions should the voltage on any SENS0-7 input exceed 1.2VDC. Permanent damage to the module will result.

The SENS0-3 inputs have a small current source that is activated in sleep mode. This source is approximately 100nA, and will cause the input to float up to about 1.2VDC. If SENSE1 for example, is enabled, pulling the SENS1 pin to GROUND will wake the device. An open drain FET is a good device to tie to the pin. The threshold is about 500mV. Additional pullup to 1.2VDC may need be used if the circuit has an impedance (due to leakage current) of less than 5Mohms (500mv / 100nA). SENS0-3 pins that are not used should be left unconnected.

10.3 Wake on UART

When the module is in Sleep mode, the UART itself is disabled. However, wake on UART can be accomplished by connecting the SENS1 pin to the RX data pin. (using appropriate divider resistors mentioned above) The SuRFboard for example, has built in resistor dividers to allow wake from RXD or CTS pins.

To enable wake on RXD , use **set sys trig 1**.

It should be noted that the first (or possibly multiple) byte sent into the module will likely be lost, so the designer should take care to send a preamble byte to wake up the module before sending valid data bytes. A better way to do this is to use the CTS input to wake the module, and wait until it is ready to accept data. To enable this, use **set sys trig 2**.

10.4 UART Receiver, RTS/CTS Hardware Flow Control

The UART receive buffer is approx. 1024 bytes, and at lower baudrates (9600, 19200) the system can process data into the device without need for flow control.

If constant streaming of data into RX on the device is required, care should be taken to set the comm parameters to optimize the performance. If data has a termination char, this can be used. Also, if data has a particular frame size, this can be used.

set comm match <value> sets the value of the packet terminator.

set comm size <value> sets the number of bytes to receive before forwarding
0-1 forwards immediately. maximum value = 1460 bytes.

The **comm size** is automatically set whenever the baudrate is set, but can be modified.

Even at higher baudrates (115K and higher) it is possible to operate without flow control if packets are uniform and a protocol is used to ensure that data is delivered on the remote side before the next packet is sent.

However, given the uncertainty of packet delays in a TCP/IP network and the affects of interference and retries inherent in wireless networks, flow control is usually required to guarantee no data is lost.

By default flow control is disabled. To enable hardware flow control, use **set uart flow 1**.

10.5 Setting GPIO direction, Alternate Functions and Disabling LEDs

The direction of the GPIO can be controlled with the GPIO mask using the **set sys mask <value>** command to set the GPIO pin direction. Value is entered as a hex number. If you need to set only one bit in the mask you need to read, mask and set the value. Otherwise you will over write any previous GPIO settings.

The hex value represents a bit mask that controls each input where 1 = output and 0 = input. For example, **set sys mask 0x0** sets all pins to input.

To set only the

The **get sys** command will show the setting of the GPIO mask.

```
<2.09> get sys  
SleepTmr=0  
WakeTmr=0  
Trigger=0x1  
Autoconn=0  
IoFunc=0x0  
IoMask=0x24f0  
PrintLvl=0x1
```

When changing the direction of a GPIO you need to read mask and set the only the bits your interested in otherwise you may unintentionally change other GPIOs

The table below shows the usage of the GPIO pins with their default state and functionality.

Bit Position	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Signal Name	GPIO-13 UART RTS	GPIO-12 UART CTS	GPIO-11 UART- RX	GPIO-10 UART- TX	GPIO 9	GPIO 8	GPIO 7	GPIO 6	GPIO 5	GPIO 4	N/A	N/A	N/A	N/A
Default State	Output	Input	Input	Output	Input	Input	Output	Output	Output	Output	N/A	N/A	N/A	N/A
Default Function	If HW Flow control enabled, toggles HIGH to indicate RX buffer full	Goes HIGH on POWERUP, LOW once system is READY. Throttles transmitter if HW flow control is enabled. LOW enables transmitter, HIGH disable.	UART RX	UART TX	ADHOC MODE & FACTORY RESET	NOT USED	BLUE LED	RED LED	YELLOW LED	GREEN LED				

Setting the alternate GPIO functions

The defaults for GPIO 4 through 6 is to control the LED functionality. This default functionality can be overridden to allow user programable IO or alternate IO functionality by using the **set sys iofunc <value>** command. Value is entered as a hex number.

The hex value represents a bit mask that controls each bit in the <value> represents a particular GPIO pin. If a bit is 0, then that GPIO is driven/read by the firmware per the default function.

The IO function <value> is encode as such:

Bit	IO	DIRECTION	Function
0	GPIO-4	output	Disable LED function so IO can be used as GPIO
1	GPIO-5	output	Disable LED function so IO can be used as GPIO
2	GPIO-6	output	Disable LED function so IO can be used as GPIO
3	Not Used		
4	GPIO-4	output	HIGH once associated/authenticated and have IP address.
5	GPIO-5	input	Set HIGH to trigger TCP connection, LOW to disconnect.
6	GPIO-6	output	HIGH when connected over TCP, LOW when disconnected.

NOTE. Bits 0-3 are mutually exclusive with the bits 4-6. i.e. 0x77 is an illegal value.

To view the current setting of the GPIO use the **get port** command
<2.09> get port
Port=30

Controlling connections with GPIO

In embedded applications it is useful to monitor and control the status of the TCP/IP connection. This can be done by using the alternate function for GPIO-5 and GPIO-6.

With the alternate function for these GPIO set, the module will connect to the stored remote host IP address and port when GPIO-5 is driven high and disconnect when driven low.

The TCP/IP connection status can be monitored by reading GPIO-6, high = connected, low = not connected.

Here is how to set the WiFly module to connect using GPIO-5 and GPIO-6

```
<2.09> set ip host <addr> // set the IP address of the remote host
<2.09> set ip remote <port> // set the IP port of the remote host
<2.09> set sys iofunc 0x60 // set alternate function for GPIO-5 and GPIO-6
<2.09> save
<2.09> reboot // the module must be rebooted for the alternate settings to take effect
```

On the remote host run your application or other software that opens and listens on the <port>.

Connect GPIO-5 to your embedded processor or other control signal. When GPIO-5 is driven high a connection will be attempted. When drive low the connection will be closed. **Be sure to not drive the GPIO with more than 3.3 VDC or permanent damage to the module will occur.**

If the connection to the remote host is successful GPIO-6 will go high. If the COMM OPEN and REMOTE strings are set you should see the *OPEN* messages on the UART and the *HELLO* at the remote host.

10.6 Setting Debug Print levels

There are a number of print functions that can be enabled to assist in debugging the operation and status of the module. The following command is used to control these printouts.

set sys printlvl <value> sets additional print functions. Bit-mapped value.

Bit	Function
1	Print start-up messages showing progress of association, dhcp, etc.

Once the configuration has been checked, this can then be turned off so that these messages do not interfere with the data.

10.7 Using the Real Time Clock Function

The real time clock in the module keeps track of the number of seconds since the module was powered on and the actual time when synchronized with the sNTP time server. By default the module keeps track of up time but does not synchronize with the time server since this requires being associated with a network that can access the sNTP server.

The default sNTP server is at

ADDR=129.6.15.28:123
ZONE=7 (GMT -7)

Use the **show time** command to see the current time and uptime

```
<2.09> show t  
Time=08:43:10  
UpTime=10 s
```

Time can be set by using the **time** command

```
<2.09> show t  
Time NOT SET  
UpTime=8 s
```

```
<2.09> time
```

```
<2.09> show t  
Time=08:51:31  
UpTime=15 s
```

NOTE: the WiFly module must be successfully associated with a network for the module to contact the sNTP server.

Alternatively, the module can be configured to get the time whenever it powers up by setting the time enable to 1. Any value greater than 1 gets time continuously every <value> minutes.

To configure the Wifly module to get time upon power up

```
<2.09> set time enable 1  
AOK  
<2.09> get time  
ENA=1  
ADDR=129.6.15.28:123  
ZONE=7
```

To view a complete listing of the time variable use the command

```
<2.09> show t t  
Time=09:02:10  
UpTime=653 s  
Powerup=1792 s  
RTC=7753271426558 ms  
timera=66885
```

10.8 Using the UDP Broadcast function

The WiFly module can be setup to automatically generate UDP broadcast packets. This is useful for a number of reasons:

- Some Access Points will disconnect devices that sit idle and don't send any packets after a time. Using the UDP broadcast informs the AP that WiFly is alive and wants to stay associated.
- This feature can be used by application programs to auto-discover and auto configure the WiFly module. If an application is listening for the UDP broadcast, a number of useful parameters are present in the package that can be used for auto-discovery. For example, the IP address and port number of the WiFly are both part of the packet, and thus the Wifly can be connected to and configured remotely with this information.

- The MAC address of the associated AP, channel, and RSSI value are available in this packet, thus enabling a simple location and tracking based function.

By default the Wifly module now sends out a UDP broadcast to 255.255.255.255 on port 55555 at a programmable interval. The broadcast address, port and interval are set using the **"set broadcast"** commands.

The format of the packet is: 72 bytes of data:

MAC addr of AP	Channel	RSS I	Local TCP port	Real Time Clock	NTC temperature/sensor 7	Spare	ASCII time of day	Version and datecode	Device ID
----------------	---------	-------	----------------	-----------------	--------------------------	-------	-------------------	----------------------	-----------

bytes:	size	
0-5	6	MAC address of AP
6	1	Channel
7	1	RSSI
8	2	local TCP port#
10	4	RTC value
14	2	NTC temperature option
16	2	Spare sensor reading
18	13	ASCII time
32	26	Version string with date code
60	32	Device ID string

11 Joining Networks and Making Connections

Configuring the module to make connections is a two set process. First you need to associate with a network access point and second you need to open a connection.

To configure the module over the WiFi link is a chicken and egg problem. The module must be associated to a network to connect to it and program the network settings. This problem can be solved by configuring the module from the UART or over the air using adhoc mode.

If configuring the module using adhoc mode, see section 13. Once in adhoc mode open up a telnet window on IP address 169.254.1.1 port 2000

If configuring the module using the UART mode either using the RS232 or development board, open a terminal emulator on the COM port associated with that device. The default baud rate is 9600, 8 bits no parity.

11.1 Associate with a network access point

From within the terminal window, put the WiFly GSX module into command mode by typing \$\$\$ in the terminal window. You should get CMD back confirming you are in command mode.

Type **show net** to display the current network settings.

```
CMD
show net
SSid=TheLoft
Chan=6
Assoc=OK
DHCP=OK
Time=FAIL
Links=1
<2.03> █
```

Now finding all available networks with the **scan** command

```
CMD
scan
<2.03>
SCAN:Found 6
Num      SSID      Ch  RSSI   Sec   MAC Address      Suites
1        roving1   01  -64    Open  00:1c:df:4f:45:9e  104    4
2        NETGEAR   01  -58    Open  00:22:3f:6b:95:42  104    0
3        07FX12018434 06  -73    WEP   00:18:3a:7e:71:d7  1104   0
4        TheLoft   06  -51    WPA2PSK 00:0c:41:82:54:19 AESM-AES 1100   0
5        airlink-11 11  -53    WPAv1 00:18:02:70:7e:e8 TKIPM-TKIP 3100   ac
6        sensor    11  -52    Open  00:1c:df:cc:aa:d8  100    1
```

If the network you're connecting to is open, you can simply use the join command to associate with the access point. From the scan list above you can see that roving1 is an open network access point. Type **join roving1** to associate with an access point.

```
<2.03> join roving1
Auto-Assoc roving1 chan=1 mode=OPEN SCAN OK
<2.03> Associated!
DHCP in lms: Renew: 86400 s
IF is UP
DHCP=ON
IP=10.20.20.62:2000
NM=255.255.255.0
GW=10.20.20.20
HOST=0.0.0.0:2000
PROTO=2
MTU=1460
bind=-10
listen FAIL
```

You could also have specified the roving1 access point by using the command **join # 1**

If the access point is security enabled you will need to set the pass phrase prior to issuing the **join** command. The RN-131G module will attempt to inquire and determine the security protocol of the access point so you do not have to set the authentication mode. To set the pass phrase for WPA use the command **set wlan phrase <string>**. For WEP set the key using the **set wlan key <num>** command.

Once you have successfully associated to the network the access point SSID is stored. This along with the pass phrase can be saved to the config file so the module can associate with the network each time it is booted up.

11.2 Making Connections

To make a connection into the module simply open a IP socket and connect to the IP address of the module. Telnet is a simple way to test this connection. From in Telnet type open <addr> <port>. In the example above the telnet command you look like **open 10.20.20.62 2000**. Once open you can type characters into the UART window and see them on the Telnet window or visa versa.

To make a connection from the module you will need IP address and port number of your server application. A simple program to test this functionality is a COM port redirector. This software opens an IP port and transfers all data it receives to a specified COM port on your machine. A free com port redirector program is available from Pira at <http://www.pira.cz/eng/piracom.htm>

After installing and starting this program, note the IP address of the machine it is running on. This can be found by running ipconfig in the Microsoft command window.

With the WiFly-GSX module in command mode, type **open <addr> <port>**. The server will report the connection is open and you can type characters into the UART window and see them on the server window or visa versa.

11.3 Setting up Automatic Connections

Often, it is desired on power up (or wakeup) to automatically connect out to a remote server, send data, and then disconnect. This can be configured to happen automatically.

In the following example assume the network SSID and security have been set correctly and autojoin is set to 1. This will also work in adhoc mode(autojoin 4), however there will be delay in connecting to the adhoc network from the remote computer so set the sleep timer large enough to allow the network to get set up and the autoconn establish a TCP connection.

When the module wakes up or is powered on the autoconn timer will cause the module to attempt a connection to the stored remote IP address and port. While this connection is open the sleep timer will not decrement. While data is flowing the idle timer will not decrement. Once data stops for 5

seconds the connection will be closed. The sleep timer will the kick in and put the module in deep sleep. Finally the wake timer will start the whole cycle again one minute later.

```
set ip host X.X.X.X      ( set up the IP address of the remote machine )  
set ip remote_port num (set up the IP port of the remote machine )  
set sys autoconn 1      (automatically connect out after READY )  
set com idle 5         (disconnect after 5 seconds with no data activity )  
set sys sleep 2       (sleep 2 seconds after connection is closed )  
set sys wake 60       (wakeup after 1 minute of sleeping )  
save
```

11.4 Controlling Connections using PIO5 and PIO6

PIO5 can be used to control the TCP connection. Once configured with the set system IO command the module will attempt to make a connection to the stored IP and PORT address when set high and will disconnect when set low.

```
set sys io 1 (configures PIO5 to connect/disconnect )
```

You can monitor the connection status by reading PIO6. High indicates an open connection, low indicates no connection. Use the command set system IO to enable PIO6.

```
set sys io 2 (configures PIO6 to represent the connection status )
```

11.5 Using DNS settings

WiFly contains a built in DNS client. If the IP address of the host is not specified (i.e it is set to 0.0.0.0) , DNS will be used. WiFLY will automatically attempt to resolve the host address stored with the command:

```
set dns name <string> sets the name of the host for TCP/IP connections.
```

Once the address is resolved an automatic connection will be made.

11.6 Utilizing the Backup IP address/connect function

WiFly contains a feature for auto-retry and redundancy. If the first IP host address connection fails, the backup IP will be used (if set) . If this fails (or is not set) then the first DNS name will be used. If this fails (or is not set) then the Backup DNS name will be used.

To set the backup IP address, use:

```
set ip backup <address>
```

To set the backup DNS name, use:

```
set dns backup <string>
```

12 Firmware Upgrade over FTP

WiFly module has a file system for storing firmware, web pages and config files. Use the **ls** command to view files. File size is displayed in sectors and the active boot image is identified in the final message.

FL#	SIZ	FLAGS	
11	18	3	WiFly_GSX-2.05
29	1	10	config

190 Free, Boot=11, Backup=0

Multiple firmware images and config files can be stored on the module file system.

FTP Upload and Upgrade

WiFly contains a built in FTP client for getting files and updating the firmware. The client uses passive mode FTP, which allows operation thru firewalls and the Internet.

To upload the latest released firmware from Roving Networks the following setting are required:

FTP username = **roving**
FTP password = **Pass123**
FTP filename = **wifly-GSX.img**
FTP directory = **./public** (this parameter can not be modified)

To use FTP to upgrade the firmware, enter the following command:

ftp upload <string> (string is an optional filename, use to bypass the default firmware filename)

The ftp upload command will retrieve the file and switch the boot image to the new file.

```
<2.10> ftp update
<2.10> FTP connecting to 208.109.78.34
FTP file=30
.....
FTP OK.
```

The previous firmware will become the backup image. Here is an example of what you should see after a successful update:

FL#	SIZ	FLAGS	
11	18	3	WiFly_GSX-2.05
29	1	10	config
30	18	3	WiFly_GSX-2.10

208 Free, Boot=30, Backup=11

Note the module must be rebooted or power cycled to use the new firmware. To boot a different firmware use the following command:

Boot image <num> sets the current boot image <num>

For example to boot the previous image from above use

```
<2.10> boot image 11
Set Boot Image 11, =OK
```

To upload your own firmware or config file to the module, change the stored FTP settings: See section 5.5 for more details on the FTP commands. To upload your file w following command:

ftp get <string> Retrieves remote file with name <string>

13 Adhoc Networking Mode

13.1 Infrastructure and adhoc comparison

There are two types of networks. The most common network is infrastructure in which an access point (AP) is the common point linking all WiFi devices. The access point keeps track of who's on the local network and directs IP packets. In many cases the AP is also a router and will forward packets from the local network to other networks and the internet. It is also very common for the AP to be running a DHCP server which tracks and assigns IP addresses.

Adhoc is considered a point to point network in that each WiFi device is linked directly to every other WiFi device on the Adhoc network. There is no access point. All WiFi devices on the adhoc network participate in keeping the network alive and each keeps track of the other active devices on the network by sending and receiving beacon and probe packets. In most cases IP addresses are assigned through Auto IP, although one of the WiFi devices can be configured as a DHCP server.

13.2 Configuring adhoc mode

The WiFly GSX module can be configured to setup an adhoc network. This mode is useful for point to point communications. The WiFly device is in Adhoc mode the device looks like access point for other WiFi devices to join.

Note: currently the WiFly only supports OPEN mode for creating adhoc networks.

Adhoc mode can be set via hardware or software commands.

To enable adhoc mode via hardware:

Set *PIO9* high (3.3V) at power up. On the RN-134 *PIO9* is on J1 of the jumper block. When the module powers up in adhoc mode the WiFly module creates an adhoc network with the following

SSID: WiFly-GSX-XX where XX is the final two bytes of the devices MAC address
 Channel: 1
 DHCP: OFF
 IP address: 169.254.1.1
 Netmask: 255.255.0.0

With the adhoc jumper in place the above settings override the current saved configuration settings.

To enable adhoc mode from software:

From command mode, the module is configured for adhoc mode using the join command. You will also need to set the ssid and channel.



```

COM1 - Tera Term VT
File Edit Setup Control Window Help

CMD
<2.07>
<2.07> set wlan join 4
AOK
<2.07> set wlan ssid my_adhoc_net
AOK
<2.07> set wlan chan 1
AOK
<2.07> get wlan
SSID=my_adhoc_net
Chan=1
ExtAnt=0
Join=4
Auth=OPEN
Mask=0x1fff
Rate=12, 24 Mb
Passphrase=rubygirl
<2.07>
<2.07> set ip address 169.254.1.1
AOK
<2.07> set ip netmask 255.255.0.0
AOK
<2.07> set ip dhcp 0
AOK
<2.07> get ip
IF is UP
DHCP=OFF
IP=169.254.1.1:2000
NM=255.255.0.0
GW=10.10.10.10
HOST=0.0.0.0:2000
PROTO=TCP,
MTU=1460
BACKUP=0.0.0.0
<2.07>
<2.07> save
Storing in config
<2.07> reboot
*Reboot*WiFly Ver 2.07_06-04-2009
MAC Addr=00:12:b8:00:24:43
Adhoc on my_adhoc_net chan=1
*READY*
  
```

```
set wlan join 4
set wlan ssid my_adhoc_network
set wlan chan 1
```

Turn off DHCP and set the IP address and netmask so other devices know where to connect to the adhoc WiFly GSX. Since auto IP fixes the first two bytes of the IP address you want to use the netmask of 255.255.0.0 so that other device connecting to the module can be reached. Alternatively you can set the netmask to a smaller subnet if the other device's IP addresses are begin statically to the same subnet as the adhoc device

```
set ip address 169.254.1.1
set ip netmask 255.255.0.0
set ip dhcp 0
```

Be sure to save your configuration, then upon reboot the module will be in adhoc mode.


To associate with an adhoc network from another WiFly device:

```
set wlan ssid my_adhoc_network
reboot
```

or alternatively you can use the join command to associate with the adhoc network. Remember to disassociated using the **leave** command if you are previously associated to another network.

```
join my_adhoc_network
```

If you leave DHCP service enabled the WiFly device will get an IP address using auto IP when associating with the adhoc network. By definition auto IP fixes the first two bytes of subnet to 169.254.xxx.xxx. The WiFly device takes about two to three seconds to resolve the auto IP address.



```
COM7 - Tera Term V1
File Edit Setup Control Window Help
CMD
<2.07> set wlan ssid my_adhoc_net
AOK
<2.07> save
Storing in config
<2.07> reboot
*Reboot*WiFly Ver 2.07,06-04-2009
MAC Addr=00:06:66:00:0a:8b
Auto-Assoc my_adhoc_net chan=1 mode=OPEN
SCAN OK
Adhoc on my_adhoc_net chan=1
Joining my_adhoc_net now..
*READY*
Connected via Ad-Hoc on my_adhoc_net
Starting Auto-IP
AutoIP Complete
IF is UP
DHCP=ON
IP=169.254.140.10:2000
NM=255.255.0.0
GW=0.0.0.0
Listen on 2000
```

Alternatively you can statically set the IP address by disabling the DHCP service and explicitly assigning the IP address.

```
set ip      address 169.254.1.2
set ip      dhcp    0
```

You can confirm the device has properly connected to the adhoc network using the ping command.

```
ping 169.254.1.1 10
```

To use associate with the WiFly adhoc network from another computer

Open the "Control Panel / Networking and Sharing / Networking and Sharing Center" dialog in Vista or "Control Panel / Network Connections" dialog in Windows XP. From here, view available networks and select the name of the adhoc network.

Note: Once associated with the adhoc network, Vista auto IP may take a couple minutes to allocate an IP address for your computer. To work around this you can assign a static IP address in the network settings / TCP/IP / Properties menu.

Once associated with the adhoc network you can open a connection or telnet window as you would with an enterprise connection.

Note: The module does not support adhoc and enterprise network modes simultaneously.

14 Analog Sensor Capability

The WiFly-GSX has 8 analog interface inputs that can be sampled using the **show q** command. The hardware specifications on the analog input is:

Input voltage range: 0 - 400mV.

Resolution: 14 bits = 12uV.

Accuracy: uncalibrated: 5%, calibrated using precision voltage or resistor measurement: 0.01%

See the WiFly-GSX (RN-131G) data sheet for more details.

To read a sensor pin, send the following command:

show q <0-7>

send "show q <chan>" where the channel is from 0 to 7. The value returned will be 8xxxxx. the value is a sample voltage in microvolts on the channel you request, with the 8 in front as a start marker.

You can also sample multiple channels by using a Bit Mask:

show q 0x1<mask> where mask is a bit mask of the channels.

For example, to read channels 0,1, and 7, send:

show q 0x183

The return values are the format: 8<chan0>, 8<chan1>, 8<chan7>, \r\n

15 Default Configuration Settings

ADHOC PARAMETERS

Beacon 100 (milliseconds)
Probe 9 (retries before declaring adhoc is lost)

BROADCAST PARAMETERS

IP address 255.255.255.255
Port 55555
Interval 7 (seconds)

COMM PARAMETERS

Close string *OPEN*
Open string *CLOS*
Remote string *HELLO*
Flush size 64
Match byte 0
Flush timer 10
Idle timer 0
Cmd char \$

DNS PARAMETERS

IP address 0.0.0.0
Name server1
Backup backup2

FTP PARAMETERS

Server address 208.109.78.34 (roving default update server) (port at 21)
File Wifly-GSX.img
User roving
Password Pass123

IP PARAMETERS

DHCP ON (1=enabled)
IP address 0.0.0.0
Net mask 255.255.255.0
Local port 2000
gateway 0.0.0.0
host 0.0.0.0
remote port 2000
protocol TCP (server and client)

OPTIONAL PARAMETERS

Join timer 1000
Replacement char \$ (0x24)
Device ID WiFly-GSX
Password "" (not used at this time)

SYSTEM PARAMETERS

Sleep timer 0
Wake timer 0
Trigger 1 (SENS1 pin wakes up the device)
Auto connect 0

IOfunc 0
 IOmask 0x20F0
 Print level 1 (prints enabled)

TIME SERVER PARAMETERS

Enable 0 (disabled)
 Server address 129.6.15.28 (fixed to port 123 - SNTP protocol)
 Zone 7 (pacific USA time)

UART PARAMETERS

Baudrate 9600
 parity n (none, this is the only option available)
 flow 0 (disabled)
 Mode 0

WLAN PARAMETERS

SSID roving1
 Channel 0 (automatic scan)
 External antenna 0 (off - use on-board chip antenna)
 Join mode 1 (automatically scan and join based on ssid)
 Authentication mode OPEN
 Mask 0x1FFF (all channels)
 Rate 12 (24Mbit)
 Passphrase rubygirl
 Key number 1
 Key 0 0 0 0 0 0 0 0 0 0 0 0

15.1 Restoring Default configuration settings:

As of version 2.10 you can now specify a USER configuration as the factory reset settings. Prior to this release only the hardcoded factory defaults would be restored.

From command interface use the **factory RESET** command to restore the defaults.

From hardware, setting PIO9 high on power up arms the factory reset functional and toggling PIO9 five (5) times there after causes the configuration setting to restored to the factory reset.

Now however if there is a config file named "user", it is read in as the factory defaults instead of using the previous hardcoded defaults. If no "user" config file is present, the hardcoded factory defaults are used.

The "user" config file is created using the "**save user**" command which saves the current configuration settings into the "user" file.

Even if there is a "user" config file arming and toggling PIO9 7 times will override the "user" settings and restore the wifly module to the factory hardcoded defaults. This is a bypass mechanism in case a bad configuration is saved into the "user" file.

Note: Factory defaults should be saved to the config file using the **save** command and the module rebooted for the new settings to take effect.

16 Boot-up Timing Values

Function	Description	Time (in ms)
Power up	Powerup Time from Reset HIGH or power good to boot code loaded.	70
Initialization	Initialize ECOS	500
Ready	Load configuration and Initialize application	30
	Total time to READY	600
Join	Associate using channel = 0 (full channel scan, mask = 0x1FFF)	800
	Associate using channel = 0 (primary channel scan, mask = 0x421)	300
	Associate using channel = X (fixed channel)	200
Authentication	Authenticate using WPA1 or 2 (highly dependent on Access Point response)	50 - 300
Aquire IP	DHCP obtain IP address (highly dependent on DHCP server response time)	30

17 Supported Access Points

Access points that are set to MIXED mode (WPA1 and WPA2) may cause problems during association because some of these incorrectly report their security mode.

We also currently do not support WPA2-Enterprise (radius server authentication, EAP-TLS)

The Wifly GSX should work with any standard Access Point. We have tested the Wifly-GSX module with the following access points

- Cisco Aeronet series
- Linksys (both standard and openWRT linux)
- Netgear WGR614 v8
- Netgear WGN54
- DLINK dir-615 Airlink
- Apple Airport express

- ADHOC MODE (Apple Iphone, Microsoft windows PC with XP, Vista , Ubuntu Linux)

18 Release Notes

18.1 Known problems

- **The UART does not support parity, only no parity is supported.**

18.2 Current Firmware features and fixes

As of Version 2.12 9/17/2009

- Fixed problem with some newer 802.11n causing association to attempt was causing module to crash/reboot. (Such as Linksys WRT160NL)
- Fixed problem with send on match character, i.e. set comm match char. Match char is now operational.
- During an open TCP session, a second incoming connection would be accepted. Second connection is now accepted but then immediately closed.
- Hardware flow control is now supported. To enable, use the "**set uart flow 1**" command.
- DHCP renew and rebind is fully supported. Previously, DHCP renew/rebind would update IP settings, and if a TCP session was active it would enter a hung state. TCP connections now survive a DHCP renew/rebind.

Features

- **TCP connection password.** This optional pass word is enabled with the command "set ip pass <string>", incoming connections will be challenged and the stored password must be matched or the connection will be closed.
- **UART instant baudrate** The **set uart instant <rate>** command immediately changes the baudrate. This is useful when testing baudrate settings, or switching baudrate "on the fly" remotely while connected over TCP.
- **Analog interface commands** The "show q" command will now enable and show the digital value of the analog interface pins. See section 14

As of Version 2.11 9/8/2009 – Limited release (please update to 2.12)

As of Version 2.10 8/14/2009

- Added a 250ms guard band in parsing of \$\$\$\$. The module now looks for three \$\$\$\$, and only three \$\$\$\$ within a 250ms period with no additional characters following for 250 ms. **Do not send \cr or \lf after the \$\$\$\$.**
- Fixed problem with UART dropping data. In cases with large data transfers (>100KB) the UART would become over whelmed and drop data.
- We no longer pass serial data received into the UART back over telnet when in remote command mode

Features

User specified default configuration - You can now specified a USER configuration as the factory reset settings. The function of PIO9 has been changed slightly. See section 15.1

Configurable Device ID – There is now an additional user programmable device ID that can be used for storing serial numbers, product name, device type or other information. The device ID is part of the broadcast "hello" UDP message that the module sends out to identify itself. Use the command show deviceid to display the current setting. For more information on using this command see the "set optional" section command

UDP broadcast packet – By default the Wifly module now sends out a UDP broadcast to 255.255.255.255 on port 55555 at a programmable interval. The broadcast address, port and interval are set using the set broadcast commands. See section 10.8

Known Issues

Wifly Module has trouble associating with some 802.11.n access points. The module will crash and reboot repeatedly. We have seen this behaviour with Linksys and Dlink router/access points. If you disable the .n capability on the router the module will associated correctly.

Flow control is not functional.

Current Firmware Version 2.09 7/10/2009

- Sleep mode was drawing 70uA instead of the expected 4uA due to an oscillator that was not disabled before going to sleep. Refer to the RN-131G datasheet for the proper low-power hardware configuration.
- Fixed closing of TCP port on TCP RESET. Previously the module was not handling remote TCP reset correctly and would disconnect which resulted in a printout of ERR= -5, TCP port was not closed properly.
- Fixed clearing and setting of strings in several set commands. In these cases the strings could be erased, but not reset.
 - set comm remote
 - set comm open
 - set comm close
 - set dns name
 - set dns backup
- Removed extra character in UART output. Previously the module would insert an extra "\r" character when '\n' appears in data stream.
- Added the **get everything** command to dump out all configuration settings
- Fixed the alternate I/O functions to allow connection based on PIO5. The manual has been updated to include a much better description of this functionality. See section 10.5

As of firmware version 2.08 6/08/2009

- Connecting out an IP address does not use the DNS and backup DNS if the connection to the primary IP address fails. Connecting using DNS if the IP address if 0.
- UART hardware flow control not yet functional.
- TCP_NODELAY added as default. This improves performance as the stack no longer waits for each TCP packet to be ack'ed, (since many Microsoft systems only ack every OTHER packet).
- Set ip proto is now a bitmask. It is possible to have both UDP and TCP bits set. If TCP enabled, UART RX data will be forwarded via TCP if a connection exists. Otherwise, data will forward over UDP (if UDP bit is set).

As of firmware version 2.07 6/04/2009

Command changes

- set wlan antenna < 0 or 1 > command has been changed to set wlan extant <0 or 1 >.
- set wlan auth <value> command has been added
- **set wlan hide** will hide the WEP key or WPA passkey. To unhide, you set key or passphrase again.
- **set ip proto 8** TCP client mode, (no listen server) only outbound connections can be made.
- Bug fixes
- Adhoc mode client associates properly
- You can now enter the WPA passkey after setting the SSID, previously the pass key had to be entered first for the security hash to be correctly created.
- Auto join now stops after 3 retries.

Features

- **show net** now displays the wifi TX rate, and correctly displays authenticated state and shows authentication mode that was used.
- **ping h** will ping the stored host address. If no host address stored, will attempt to use the DNS hostname.
- **ping i** command added to ping a known Internet server (www.neelum.com) by first resolving the address, proving that DNS is working and then pinging the server. This proves the device has internet connectivity.
- UDP secure mode will only forward packets to the UART that match from the host address. TCP secure mode will only allow connection from and IP that matches host address.

As of firmware version 2.06

- Web server interface is not available – Configuration over telnet and the UART
- UART flow control is not functional – The module may drop data at high data rates
- Sensor pins for reading analog signals are not supported
- Wake on UART RXD or CTS is not working on current revision REV2 of the SuRFBBoard.
- The fast- autosleep timer for UDP mode is not implemented.

Fixes since fimware version 2.05

- Configuration over Telnet not functional
- Error checking the correct number of parameters